
Flame Sensor

<u>Harsha R</u>

1BM18CS034

<u>Aim</u>: To detect and alert an instance of a fire.

Circuit Diagram



Handwritten Code

Code

```
int temp_pin = A0;
int led_pin = 13;
int buzzer = 9;
void setup()
{
   Serial.begin(9600);
```

```
pinMode(led_pin,OUTPUT);
      pinMode(buzzer,OUTPUT);
}
void loop()
{
 float input = analogRead(temp_pin);
float mVolts = (input/1024.0)*5000;
 float celcius = (mVolts-500)/10;
 if(celcius>45){
 digitalWrite(led_pin,HIGH);
  digitalWrite(buzzer,HIGH);
 }
 else {
 digitalWrite(led_pin,LOW);
  digitalWrite(buzzer,LOW);
 }
 Serial.print("Temperature: ");
 Serial.println(celcius);
 delay(500);
}
```

Observation

In case of a fire, the led starts glowing and the buzzer starts ringing to alert about it.

Output



" Serial Monitor

Temperature: -4.10 Temperature: -4.10 Temperature: -4.10 Temperature: -8.98 Temperature: 66.70 Temperature: 99.90 Temperature: 99.90 Temperature: 99.90